

QUICK START GUIDE

Included in this Package:

- *LaserShield Master Alarm Unit (MAU)*
- *LaserShield Wireless Detection Unit (WDU)*
- *2 Keychain Remotes*
- *8' foot Telephone Cord*
- *2 AC Power Adapters*
- *Monitoring Service Agreement*
- *Monitoring Service Information Form*
- *Owner's Manual*
- *Product Registration Card*
- *2 Emergency Wallet Cards*
- *Warning Decals*
- *Pet Shield*



Security Made Simple™



1

ACTIVATE EMERGENCY RESPONSE SERVICE


You are not fully protected until you activate Emergency Response Services

(if your Emergency Response account was created at the retailer where you purchased your LaserShield you can skip this step)

- Go to www.lasershield.net
- Click on "Activate" LaserShield®
- Prepare to enter the 8 character Device ID Code located on bottom of MAU
- Follow instructions on the web page

NON-INTERNET USERS

- Fax or mail Activation Forms (included in box) to LaserShield® Customer Care



24/7 Monitoring

Professional Response

Immediate Notification



- Wait for LaserShield® Customer Care to contact you to request you to test the system and confirm activation

www.lasershield.net


NOTE: You can activate your Emergency Response Services instantly by using the Internet. If you activate Emergency Response Services by mail or fax, you may use your LaserShield System as a local alarm, without the benefits of monitoring, to deter intruders while you are waiting for your Emergency Response Services to be activated.

2

MASTER ALARM UNIT (MAU)

PLUG & POWER

- Plug one of the AC power adapters into a wall outlet and insert the connector into the power port on the rear of the MAU
- Connect one end of the phone cord to a live telephone jack. Connect the other end to the phone jack labeled TO WALL on the rear of the MAU. (DSL phone lines require the insertion of a DSL filter between the MAU and the wall phone jack)
- Remove battery tab on bottom of MAU to enable battery backup
- Press and hold ON/OFF button until the unit announces "LaserShield On"



Master Alarm Unit (MAU)

Press Button to Turn On/Off



Wall Phone

NOTE: Do not place other electronic devices or objects on top of the MAU.


3

WIRELESS DETECTION UNIT (WDU)

PLACE, PLUG & POWER

- Place Wireless Detection Unit (WDU) to cover desired area for protection
- Plug the remaining AC power adapter into a wall outlet and insert the connector into the power port on the rear of the WDU
- Remove battery tab on bottom of WDU to enable battery backup
- Press on/off button on rear of unit until red power LED on the front panel illuminates

NOTE: Optimum height is 3' to 5' above floor. Positioning and aiming unit from a corner delivers best protection. Position so there are no obstructions to unit's view. See LaserShield® Owner's Manual for using your system with pets.




Recommended Placement for the WDU

4

LEARN & LINK DEVICES

You must link your Keychain Remotes and WDU's to the MAU for the system to work:

1. Press Learn button on rear of MAU
2. One keychain remote at a time, press the ARM and DISARM buttons together (MAU announces "Keychain number X stored in memory")
3. Press the red Panic button on each Wireless Detection Unit (MAU announces "Satellite number X stored in memory")



Press Both Buttons Together



NOTE: Pressing Panic button on MAU during Learn Mode will erase all devices.

5

EXIT LEARN MODE

- Press Learn button on rear of MAU
- MAU will announce an inventory of the devices successfully learned into the system (If fewer than one keychain remote AND one WDU are learned into to the system the MAU will announce "System Disabled". Return to step 4 to learn the missing keychain remotes or WDUs)

NOTE: Be certain all devices are acknowledged by the MAU.

Press Button to Exit Learn Mode



6

TEST SYSTEM

1. Press a Panic button
Let the siren sound for about 10 seconds
2. Disarm system with Keychain Remote
3. Have your 5 digit passcode handy
(you'll find this passcode on the wallet cards inside the document package included with your Lasershield)

1 Press Panic Button to Test



2 Press Button to Disarm



4. Answer the phone call from Rapid Response Monitoring that you'll receive on your premises telephone in approximately 30 seconds
5. Respond to the voice prompts using your telephone keypad
6. When this test is successful the voice on the phone will announce that your account is activated

7

ARMING AND DISARMING

- When you leave the premises, press the Arm button on your Keychain Remote to arm the system
(MAU will announce "LaserShield Arming")
- Exit within 60 seconds
- When you return to the premises, press the Disarm button on your Keychain Remote to disarm the system
(MAU will announce "LaserShield Disarmed")

Press LEFT Button to Disarm



Press RIGHT Button to Arm

NOTE: When returning, a warning tone will beep for 20 seconds to remind you to Disarm.

8

ARMING AT NIGHT

- If you wish to bypass a Wireless Detection Unit (e.g. in a bedroom) press the Bypass button on that unit
- Press the Arm button on your Keychain Remote
(MAU will announce "LaserShield disarmed, Satellite number X bypassed, fix the condition or press the arm button again to force arming")
- Press the Arm button a second time
(MAU will announce "forced arming")

Press Button to Bypass



NOTE: Remember to press Bypass button to re-enable unit before leaving your premises.
MAU will always announce any bypassed unit during arming.
WDU Panic buttons still work during Bypass mode.

CONTACT INFORMATION

Please contact LaserShield Customer Care at 1-800-ALARM-55 if you have any questions, or visit our web site at www.lasershield.net to get the latest information on using your LaserShield Security System.

LaserShield® Security Systems, Inc.

LaserShield Customer Care
LaserShield Systems, Inc.
277 E. Amador, Suite 304
Las Cruces, NM 88001

© 2008 LaserShield® Systems, Inc. All Rights Reserved.